

Abstract Submitted  
for the MAR09 Meeting of  
The American Physical Society

**Complex refractive index of graphene measured by picometry** XUEFENG WANG, DAVID NOLTE, Purdue University — The complex refractive index  $\tilde{n}_g$  of graphene remains unresolved because the traditional technique, ellipsometry, fails when applied to graphene with its sub-nanometer thickness, dielectric anisotropy, and small transverse sample size. Here we apply interferometric picometry to measure  $\tilde{n}_g$  at 488 nm, 532 nm and 633 nm. A strong dispersion of  $\tilde{n}_g$  was found in the visible region.  $\tilde{n}_g$  varies from 2.4-1.0i at 532 nm to 3.0-1.4i at 633 nm at room temperature. The dispersion is five times stronger than bulk graphite (2.67-1.34i to 2.73-1.42i from 532 nm to 633 nm). In experiments, Graphene is deposited on a substrate with complex reflection coefficient  $\tilde{r}$  tuned near an antinode condition. As a dielectric film, graphene modifies  $\tilde{r}$  of the substrate into  $\tilde{r}'$ . Picometry measures both the amplitude and the phase change of  $\tilde{r}$ , and therefore acquires the full information needed to calculate  $\tilde{n}_g$ . This is accomplished by scanning a normal-incidence focused Gaussian beam (1.5  $\mu\text{m}$  width) over the graphene and monitoring the asymmetric diffraction of the reflected beam. Picometry measures the complex change of  $\tilde{r}$  with a quadrant detector that simultaneously monitors both intensity and axis shift of the reflected beam and calculates  $\tilde{n}_g$ . The strong dispersion of graphene is reported here for the first time, and it is likely caused by the strongly modified quantum level structure of the single atomic layer.

Xuefeng Wang  
Purdue University

Date submitted: 20 Nov 2008

Electronic form version 1.4